


美容月亮灯使用说明书



1.技术规格

产品型号	HD-M8X
输出电压	110V/240V 50Hz/60Hz
功率	45W
可调节亮度	0%~100%
色温	3000K-6000K
显色指数	RA>80
流明值	4800LM
灯头尺寸	700*230*70mm
产品重量	5.5kg

2. 产品部件介绍



- 注意事项: 完成组装后, 请将灯头和底座调整为同一方向。


3. 组件安装

3.1 固定连杆A和灯头

- ①将电源线从连杆A右侧口部往外拉
- ②将左侧锁紧螺母与灯头螺丝连接并旋转固定。



3.2 将伸缩杆B支撑杆C、D和基座连接

- ①将松紧螺母E拧松后转动B杆连接A杆螺丝接口。
- ②将支撑杆C和支撑杆D的螺丝接口旋转固定好。
- ③旋转支撑杆D固定到基座螺丝接口锁紧。
- ④旋转螺母E锁紧伸缩杆B和支撑杆C。
- ⑤将适配器与灯头灯头线DC口连接, 并连接上交流电后, 灯具可以正常工作。



4. 调节亮度和色温

- 4.1 调节亮度:转动右侧按钮, 开关灯光并调整亮度 0-100%
- 4.2 调节色温:转动左侧按钮, 可将色温在 3000K-6000K之间调节。



注意: 先转动电源开关旋钮, 再按遥控电源开关键, 即可切换到遥控模式。

5. 遥控器包装清单

- | | |
|---------------|-------|
| 1. 灯头 | —— 1个 |
| 2. 36V1.5A适配器 | —— 1个 |
| 3. AC电源线 | —— 1条 |
| 4. 说明书 | —— 1张 |
| 5. 底座 | —— 1个 |
| 6. 支撑杆D | —— 1条 |
| 7. 支撑杆C组件 | —— 1条 |
| 8. 手机支架管夹 | —— 1个 |
| 9. 手机支架 | —— 1个 |
| 10. 遥控器 | —— 1个 |

6. 注意事项

- 6.1.在使用前认真阅读说明书并按照说明书正确安装产品。
- 6.2.拍摄时请把环形灯固定在灯架上。
- 6.3.产品只能在额定电压下使用。
- 6.4.不要用拉电线来试图拔掉插头, 也不要用手去触碰插头。
- 6.5.该产品应该放置于干燥通风处, 以免潮湿处使电路板受潮, 导致电路发生短路故障。
- 6.6.停止使用时, 请关掉电源, 以免长时间发光而影响灯具的寿命。


Instructions for LED Moon Light



1.Technical specifications

Model	HD-M8X
Input power	110V/240V 50Hz/60Hz
Output power	45W
Adjustment range	0%~100%
CCT	3000K-6000K
CRI	RA>80
Lumen	4800LM
Size	700*230*70mm
Weight	5.5kg

2.Detail



- Note:Please set the lamp and base on same direction for safe use.


3. Assembly Instructions

3.1 Mount part A and lamp

- ① Pull the power cable out of the right mouth of connecting rod A
- ② Rotate the screw of part A to connect the lamp.

3.2 Connect the telescopic rod B supporting rod C and D to the base



- ① Loosen the loosening nut E and turn rod B to connect the screw connector of rod A.
- ② Rotate and fix the screw interfaces of support rod C and support rod D.
- ③ The rotating support rod D is fixed to the base screw interface and locked.
- ④ Rotating nut E locks expansion rod B and support rod C.
- ⑤ Connect the adapter to the DC port of the lamp head line, and connect the AC power, the lamp can work normally.



4. Adjustment instruction

Power adjustment:press the swich knob to turn on the power switch.The power can be adjusted step by step from 1% to 100%,increasing clockwise and decreasing step by step in the countclockwise direction.Each toggle button changes by 1%.

CCT adjustment:the color temperature can be adjusted from 3000k to 5600k,gradually increasing in the clockwise direction,decreasing in the counterclockwise direction,and changing the toggle button by 100k.



Note: First turn the power switch knob, and then press the remote control power on key, you can switch to the remote control mode.

5. Remote control packing list

- | | |
|---------------------------|---------|
| 1. Moon light | —— 1pcs |
| 2. 36V1.5A adapter | —— 1pcs |
| 3. AC charger power cable | —— 1pcs |
| 4. Manual | —— 1pcs |
| 5. Base | —— 1pcs |
| 6. Stand part D | —— 1pcs |
| 7. Stand part C assembly | —— 1pcs |
| 8. Cellphone holder | —— 1pcs |
| 9. Cellphone stand | —— 1pcs |
| 10. Remote control unit | —— 1pcs |

6. Cautions:

- 6.1.Please read the manual carefully and install the lighting according the instruction sheet before using.
- 6.2.Please fix the lighting on the bracket.
- 6.3.The ting lighting shall be used within the normal voltage.
- 6.4.Don't pull the cable to turn off the power and don't touch the plug with wet hand.
- 6.5.The ring lighting shall be keep a dry and ventilated place.
- 6.6.When stop using please cut off the power to avoid the short circuit.